

## AWN542 Extra Cycle Features

The AWN542 has a fabric selector switch that separates control of the agitation and spin selection speeds from the timer. This option gives the user more control over the wash cycle when compared to other models. All other models incorporate the agitation and spin operations into the cycle selection timer.

A *KNITS* or *DELICATE* fabric selection with a *REGULAR* or *PERMANENT PRESS* cycle selection delivers a constant slow agitation coupled with selectable fast or slow extraction spin. None of the other models operate with the constant slow agitation feature in a complete cycle. The AWN542 continues to incorporate traditional *Delicate* and *Hand Wash* cycles that utilize intermittent slow agitation, extended soaks, and slow speed spins to perform a gentle wash. Another unique option is the ability in the *SOAK* cycle to use a fast or slow agitation and spin extraction.

See the chart below for a detailed breakdown of agitation and spin speed selections.



FABRIC SELECTOR	CYCLE SELECTION TIMER				
	Regular	Perm Press	Delicate	Hand Wash	Soak
Regular	F/F/F	F/S/F	S/S/S*	S/S/S*	F/F
Perm Press	F/S/S	F/S/S	S/S/S*	S/S/S*	F/S
Knits	S/F/F**	S/S/F**	S/S/S*	S/S/S*	S/F
Delicate	S/S/S**	S/S/S**	S/S/S*	S/S/S*	S/S

Soak cycle agitates for 3 min at beginning of cycle then soaks for 12 min then spins for 3 min

### Agitation/Spin & Spray/Final Spin

Fast (F) = 68 strokes per min or 710 RPM spin

Slow (S) = 47 strokes per min or 474 RPM spin

\* Agitation with pauses and soaks

\*\* Constant slow agitation